

## You should have the following component parts:

- Panels with legs loosely attached (3,4,5 panels depending on model ordered)
- Allen Key
- Spare Wheel x 1

Your Screens will be supplied flat packed and ready for easy assembly:

## To Assemble

- Step 1 - Take the panels out of the box. Pic 1. Take care not to discard pack containing allen key and spare wheel. NOTE: Panels will already be attached to each other in the correct order. **DO NOT CHANGE THIS ORDER OR COMPLETELY REMOVE ANY OF THE PANELS.**
- Step 2 - Unfold the panels out on the floor. The legs will be loosely attached to each panel. Pic 2. Whilst flat on the floor work along each panel turning each corresponding leg so it is at a 90° angle to each of the panels. Pic 3.
- Step 3 - Once legs are positioned at 90° secure in place using the allen key provided to tighten the screw. Pics 4 & 5. Tighten the screw fully so that the leg is pulled securely into the plastic housing, fixing it into place. Pic 6. Ensure the plastic housing grips snugly over the leg. Pic 7.
- Step 4 - Repeat for each panel leg.
- Step 5 - Carefully lift the panels from the floor to stand up. Once standing it is important to make sure the frame panels are level with each other.



## Troubleshooting

